



### ALPHASORB TACKABLE ACOUSTIC PANELS

#### Finishing Nails and Adhesive

Installation of tackable wall panels is simple.

1. Mark where you want the panel to be installed on the wall.
2. Apply a tennis ball-sized mound of construction adhesive on the back of the panel, about every 1.5 feet, 7-8 inches from the edge of the panel.
3. Place the back of the panel to the wall, firmly pressing on areas with adhesive, and adjusting to line up with the marks made in step 1.
4. Apply finishing nails along the edge of the panel while another person holds the panel in place.

