

Green Glue Noiseproofing Sealant

PREPARE FOR APPLICATION

Make sure the surfaces that are to be sealed are clean. Cut a ¼" hole in the tip of the tube with a utility knife. Screw nozzle tightly over the tip of the tube and cut a ¼" hole in the tip of the nozzle. When your nozzle is cut, place the tube in a standard 28 ounce caulk gun to prepare for installation.

INSTALLING GREEN GLUE NOISEPROOFING SEALANT

A very common application of Noiseproofing Sealant is filling 1/8" to 1/4" gaps between drywall joints, and areas where the drywall meets the floor and ceiling. Other applications include spaces around electrical outlets, windows, doors, and light fixtures.

Apply 48 hours before painting to allow for drying time. Drywall mud can be applied directly over Green Glue Noiseproofing Sealant.



Please Note: These installation instructions are given as a general guide to avoid common errors. Installer should follow best practices for construction and workmanship. Acoustical Solutions bears no responsibility for installation or contractor selection. Please contact a sales representative if you have questions, concerns or specific project requirements.

Be sure to inspect materials upon delivery. Please note any damage on the delivery ticket and notify Acoustical Solutions immediately. Materials should be stored in original packing in a clean, climate controlled environment free of moisture. Installation should not commence until building is enclosed and under standard occupancy conditions and surfaces are of clean, acceptable condition and properly prepared. Installation is best done at the end of a construction project. Do not install materials of unacceptable quality.

