

## Fabric Wrapped Panel Installation: Rotofast Snap-On Anchor

The following installation instructions are given as a general guide to avoid common errors. Installer should follow best practices for construction and workmanship. Acoustical Solutions bears no responsibility for installation or contractor selection. Please contact a sales representative if you have questions, concerns or specific project requirements.

Be sure to inspect materials upon delivery. Please note any damage on the delivery ticket and notify Acoustical Solutions immediately. Materials should be stored in original packing in a clean, climate controlled environment free of moisture. Installation should not commence until building is enclosed and under standard occupancy conditions and surfaces are of acceptable condition and properly prepared. Do not install materials of unacceptable quality.

### INSTALLATION METHOD

Acoustical panels typically ship with the appropriate amount of Rotofast Snap-On Anchors and accessories required for the project. The anchors are pre-installed into the back of the panel. The appropriate amount of marking plugs for the largest panel and ratchets are included. The recommended two inch #8 screws and wall anchors (not included) are to be provided by the installer.

