

ALPHASORB[®] FABRIC WRAPPED BASS TRAP INSTALLATION GUIDE

INSTALLATION

AlphaSorb[®] Fabric Wrapped Bass Traps can be mounted in any 90° corner between two walls or a wall and a ceiling.

- The trap can be attached directly to the surfaces using hook and loop Velcro. **Note:** For best results, clean wall surfaces before applying the pressure sensitive adhesive backing on the Velcro to the wall or use a hot glue gun to attach the Velcro to the wall.
- Water-based construction adhesive can also be used to adhere the corner trap in place. **Note:** We recommend Loctite[®] Power Grab or another water-based construction adhesive which can be used in any standard caulk gun.
- If there is no 90° corner available, or if the corner is not suitable, AlphaSorb[®] Fabric Wrapped Bass Traps can be stacked in a freestanding configuration.

