

## ALPHASORB<sup>®</sup> FABRIC WRAPPED QUICK SHIP BASS TRAP INSTALLATION GUIDE

### BASS TRAP INSTALLATION

Determine the bass trap locations. Measure out from the corner and lightly mark the edge location of where the corner impaling clips will be mounted. Be sure the clips are installed at least 6" from the bottom or top edge of the panel to avoid the fabric on the back of panel. Mount clips to the wall surface using the provided screws. Line up the panel to the marks on the wall and firmly push the panel down onto the angled impaling clips. Check for plumb with a level. Repeat process for multiple bass traps.

