

Desktop Sound Masking System

To set the volume and contour of the unit, use a small screwdriver (not included).

At the back of the unit, there are three blue potentiometers (or “pots”) that can be adjusted for gain control (volume), contour (frequency) or paging volume. In addition, in the center of the back of the unit there is a silver potentiometer. This is the primary gain (volume) control and is referred to as the “Center Pot.”

Please note that in the desktop unit, no controls to the paging volume will be necessary.

1. To set the unit, first plug in the unit and turn it on using the on/off switch at the side next to the power cord.
2. Adjust the center screw terminal by inserting a screwdriver into the silver Center Pot and turning it counterclockwise until it stops and then turn it back clockwise 4 clicks.
3. Now adjust the contour (sound frequency) by inserting the screwdriver into the blue Contour Pot and turning the dial all the way counterclockwise.
4. If additional volume attenuation is required you can use the silver center pot or the blue gain control pot to adjust the sound in 1/2 dB increments until you reach your preferred volume level.

