

## ALPHASORB<sup>®</sup> SERIES 300 POLYESTER PRODUCTS CLEANING GUIDE

### CLEAN AND MAINTAIN

1. Pat the spills as soon as possible, to avoid liquid/stain to be absorbed into the product.
2. If there is visible soil and stain is dry, use a bristle brush to loosen the dirt. Avoid excess pressure.
3. Vacuum the surface thoroughly.
4. Based on the situation, apply the recommended cleaning solution to a lint free cloth. Use a hand spray application, and avoid over-soaking the surface.
5. Using the sprayed cloth, pat the stain starting from the outer edge and moving inward.
6. If required, get another new cleaning cloth. Repeat procedure until there is no further transfer of the dirt to the cloth.
7. Once the stain is removed, soak up all remaining cleaning solution with a dry cloth.
8. Use a clean cloth or sponge soaked in water to remove any residue.
9. Allow treated surface to air dry.

### DISINFECT

Proper personal protective equipment must be worn (bleach odor respirator, protective eye wear and gloves).

### SOLUTION

- 50/50 solution of warm water and bleach (5.25% sodium hydrochloride solution)
- 3% Hydrogen peroxide
- Distilled water (for stain removal only)
- Aerosol disinfectants, such as Lysol

### STEPS

1. Mix equal amount of bleach and water.
2. Mist the surface of the product with a hand spray applicator. Apply generously.
3. Allow surface to air dry.

These cleaning and disinfecting instruction meet CDC guidelines.

