

PRIVACYSHIELD[®] CEILING TILE BARRIER INSTALLATION GUIDE

The following installation instructions are given as a general guide to avoid common errors. Installer should follow best practices for construction and workmanship. Acoustical Solutions bears no responsibility for installation or contractor selection. Please contact a sales representative if you have questions, concerns or specific project requirements.

Be sure to inspect materials upon delivery. Please note any damage on the delivery ticket and notify Acoustical Solutions immediately. Materials should be stored in original packing in a clean, climate controlled environment free of moisture. Installation should not commence until building is enclosed and under standard occupancy conditions and surfaces are of acceptable condition and properly prepared. Do not install materials of unacceptable quality.

KEEP CUTOUTS AND GAPS TIGHT OR SOUND ENERGY WILL LEAK THROUGH




Typically tiles are cut on a plywood surface with a standard carpentry knife and straight edge, then passed to the installers on the ladders.

It is important to keep gaps minimal between cut tile edge and grid or wall.



Composition: 0.12 inch (3.05mm) non-woven polyester acoustic decoupler bonded to a 0.12 inch (3.05mm) mass loaded vinyl sound barrier.

Fire Resistance: Class A per ASTM E84 (UL 723-2018)



Please maintain minimum gaps between sprinkler pipe and edge of cut tile.

We suggest using a Circle Cutter as a marker.

